



NIRA 67

Pressure Pump for Drilled or Traditional Wells

The Nira 67 develops around 1 bar of pressure. The spout is fitted with a ¾” internal thread, to which a standard garden hose attachment can easily be fitted. This enables moving water further, also upwards from the pump.

When used on a drilled well, the pump cylinder can be installed up to 20 metres deep using extra pipe modules. Available in a number of colours. Supplied in a light, easy to manoeuvre package.

- Maximum water volume around 40 litres/minute
- Corrosion resistant
- Weight 14 kg
- Package size 120 x 40 x 25 cm
- Warranty 36 months



List of Parts

- | | |
|--|---|
| <ol style="list-style-type: none"> 1 Cover Grey R14766H
Cover Red R14766P
Cover Blue R14766S 2 Rubber plug R406 3 Seal R14832 4 Screw R206825 5 Seal R16787 6 Screw R20610201 7 Mounting fork flange P14705 8 Bearing P14750 9 Shaft seal RSL05 10 Rocker arm P14742 11 Cotter pin R242430 12 Washer SD404 13 Handle fork mounting P14744 14 Clamping screw R21256 15 Handle P14747 16 Handle grip R93B 17 Pump head top P14749 18 Hosepipe adapter ¾” R1570713 19 Pump head pipe SD302 | <ol style="list-style-type: none"> 20 Base plate SD1804 21 Screw R2288 22 Nut R202840 23 Cylinder coupling P27 24 Cylinder plunger rod P35 25 Plunger complete P605 26 Plunger seal R56 27 Cylinder pipe P28 28 Cylinder valve R30 29 Cylinder valve body P29 30 Cylinder complete P31 31 Pump head rod SD14373 32 Riser pipe 1 m M2100K 33 Plunger rod 1 m L2102 34 Coupling SD106 <p>OPTIONAL pipe extension below the cylinder</p> <ol style="list-style-type: none"> 35 Coupling for suction pipe R26211440 36 Suction pipe R1964058 37 Bottom valve for suction pipe 1 ¼” 2002 |
|--|---|

NOTE:

The NIRA 67 is intended for pumping domestic and drinking water. The pump drains itself after use, so it does not freeze. The overall length of the pump in the basic package (code 1067SG grey / 1067SB blue / 1067SR red) is 2.5 m, measured from the pump cover to the bottom of the cylinder. The base of the cylinder features a 1 ¼” internal thread, to which an attachment to connect 40 mm polythene suction pipe can be fitted.

The maximum length of the suction pipe is 6 metres. If the suction pipe is longer than 1.5 metres a bottom valve must be fitted. The pump's cylinder can be lowered up to a maximum of 21 metres using 0.5, 1.0 or 3.0 metre pipe modules. The maximum depth the pump can reach is therefore 12.5 metres. The maximum depth of the Nira 67 is 27.5 metres from the well cover.

Comprehensive spare parts service

Nira pumps are made to last. Properly maintained they have a service life of decades. Our comprehensive range of spare parts includes parts for current and older pumps.

Find out more about spare parts at www.nira.fi

Nira Pumps Oy

Putajantie 42 / P.O. Box 54, FI-38210 Sastamala, Finland

Tel. + 358 10 830 6770 | nira.info@nira.fi

www.nira.fi

