



# NEW FROM NIRA!

The safe NIRA hand pump is now also available for parks and playgrounds

The NIRA 67 PLAYGROUND PUMP has been designed for children's play and for parks.

The pump does not need a well; it is connected to mains water supply (pressure requirement 4-6 bar). The valve in the pump opens briefly every time the handle is lifted, releases a few decilitres of water then closes again automatically. Our specially developed valve makes the pumping action feel authentic. Colour choices: red, grey or blue.



NIRA PUMPS · SINCE 1919

[www.nira.fi](http://www.nira.fi)



No danger of crushing

## Safety:

Safe handle



Sturdy base



### Materials:

- Stainless steel
- Silumin
- Plastic
- Brass

The pump is designed for summer use only (temperature range for use +2 - +50°C)

Designed and manufactured in Finland. The NIRA 67 playground pump fulfils EU standards for playground apparatus (EN 1176-1).

